



Connection Cable with Schneider Electronic Shutter

Instructions



Code: 7036K



Connect the cable code 7036K between the DRCU and the Schneider Electronic Shutter.

In the "Shutter" Menu of the DRCU, Silvestri is set as default. Press the upwards arrow to select Schneider shutter. Wait a few seconds and the following writing will show:

Shutter Schneider

F-min ...

F- max ...

Press Enter then press Menu to go back to the Ready status.